



1/15




*Fig. 1A.*

2/15




*Fig. 1B.*

3/15




*Fig. 2.*



*Fig. 3.*

5/15



*Fig. 4.*

6/15

180

188

186

VELODYNE DIGITAL DRIVE  
SYSTEM RESPONSE

[PREV]  
EXIT/SAVE

	SETUP	-----PRESETS-----					
		1	2	3	4	5	6
LOW PASS XOVER FREQ	82	80	80	80	80	80	80
LOW PASS XOVER SLOPE	82	80	80	80	80	80	80
SUBSONIC FREQUENCY	15	15	15	15	15	15	15
SUBSONIC SLOPE	24	24	24	24	24	24	24
PHASE	00	00	00	00	00	00	00
POLARITY	+	+	+	+	+	+	+
VOLUME (1 - 99)	25	25	25	25	25	25	25
CONTOUR FREQUENCY	NA	35	35	45	33	50	60
CONTOUR LEVEL	NA	2.0	0.0	3.0	0.0	0.0	0.0
THEATER/MUSIC (1-8)	NA	01	03	06	08	01	01

182


184

USE ← → KEYS FOR NAVIGATION  
 HOLD ← → KEYS FOR FAST NAV  
 PRESS TEST KEY FOR GRAPH SCREEN

AUTO ON/OFF MODE: ACTIVE  
 NIGHT MODE VOLUME %: 30


*Fig. 5.*

7/15



*Fig. 6.*


8/15



*Fig. 7.*




9/15




*Fig. 8.*

10/15




*Fig. 9.*

11/15




*Fig. 10.*

12/15




*Fig. 11.*



*Fig. 12.*


14/15

MUSIC



*Fig. 13.*

15/15



*Fig. 14.*